Fibre



## Assembly Instructions

Argosy 1U ECO Fibre Patch Panel - Economy Version

				Contents
		0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	· B · · · ·	Contents
	A, B, C, D	M20 cable entr Easy slot featur	y more commonly e allows direct at	with fixing points for universal front management v used, moved to exterior to improve routing into panel tachment of Fibre breakout manifold ting positions or bend radius management
3	Dark Grey L, (Sony Dark Grey)	New inner reces	ssed <b>¤po</b> a <b>te de</b> signe	ting positions or bend radius management ay mounting positions ed to hold adaptors tighter (no screws)
01	NC-17-00'1	Pull push mech	anism to lock and NC-16-010	l release sliding panel
)2	NC-17-002	NC-00-022	NC-16-011	
)3	NC-17-003	-	-	
04	NC-17-004	-	NC-16-012	
05	NC-17-005	-	-	
06	NC-17-006	-	•	
07	NC-17-007	-	-	
08	-	-		



ECO Patch Panel



## Assembly Instructions

Argosy 1U ECO Fibre Patch Panel - Economy Version

0 09 09 08		Installation	
1	2	3	4
Step 2 - inse Step 3 - slot	rt screws to both the easy install ea	th left & right mounting profiles bottom cage nuts - do not tighten ars to the bottom screws and tighten all screws	4

				Optional	
	Dark Grey (Sony Dark Grey)	Black vented	Gre,		
L	NC-17-001	N			
2	NC-17-002	N			
3	NC-17-003	/ P	EBBBBB	BBBBBBBBBBBBBBBB	
1	NC-17-004				
5	NC-17-005	-	-		
5	NC-17-006 retro	fit fron <u>t</u> cable i	nanagement, this	s manages the front patching field	and provides bend radius protection
7	NC-17-007	-	-		
8		•	-		


+44 1844 202101 | sales@argosycable.com | argosycable.com |





## Assembly Instructions

Argosy 1U ECO Fibre Patch Panel - Economy Version



3	(Sony Dark Grey)		10-A-03
01	NC-17-001	NC-00-010	NC-16-010
02	NC-17-002	NC-00-022	NC-16-011
03	NC-17-003	-	-
04	NC-17-004	-	NC-16-012
05	NC-17-005	-	-
06	NC-17-006	-	-
07	NC-17-007	-	-
80	-	-	-